

# Timeless Designer Towel Rail Installation Instructions



**PLEASE READ THESE INSTRUCTIONS THOROUGHLY BEFORE STARTING INSTALLATION**



Ancillary Components			
1	Blank Plug	4	Bracket Stem (e)
1	Air Vent Plug	4	Mini Screw (f)
4	Wall Plug (a)	2	Decorative Cover Cap
4	Wall Support (b)		
4	Washer (c)		
4	Wall Screw (d)		

**PLEASE CHECK THAT ALL COMPONENTS ARE PRESENT  
AND THAT THE PRODUCT HAS NOT SUFFERED ANY  
DAMAGED DURING TRANSIT**

**THIS PRODUCT IS MANUFACTURED FROM MILD STEEL & IT IS ONLY SUITABLE FOR INSTALLATION WITHIN  
A CENTRAL HEATING SYSTEMS WITH A CORROSION INHIBITOR ADDED TO THE WATER.**

Installation should be carried out by a suitably qualified professional or other fully competent person & in accordance with the relevant British and European standards (BS7593:1992, EN12828:2003, EN12831:2003 & EN14336:2004) & all applicable Building Regulations.

When drilling or fixing into walls, floors or ceilings it is essential that you check for pipes & wires before commencing. Please ensure that you wear all necessary personal protective equipment.

Due to our commitment to continuous product development we reserve the right to alter specifications without notice. Products are warranted against manufacturing defects for the first purchaser only & the warranty is non-transferable. Our liability under any guarantee expressed or implied is strictly limited to replacement of defective goods and no consequential losses of any kind will be entertained. Proof of purchase will be required for all warranty claims.

Regular cleaning with a soft cloth will keep the surface of your product looking new. Soapy water can be used to remove stubborn marks. Do not use abrasive or chemical cleaners as these will damage the surface finish over time.



**AFTER INSTALLATION THE SYSTEM MUST BE THOROUGHLY FLUSHED WITH A 'DOMESTIC  
WATER TREATMENT ASSOCIATION' (DWTA) APPROVED CENTRAL HEATING CLEANSER.  
FOLLOWING CLEANSING A DWTA APPROVED CENTRAL HEATING PROTECTOR MUST BE  
ADDED TO THE SYSTEM. FAILURE TO CLEANS AND PROTECT THE SYSTEM PROPERLY IS  
LIKELY TO REDUCE THE LIFECYCLE & INVALIDATE THE WARRANTY.**



Maximum Working Pressure 1000kPa (10 Bar)  
Maximum Working Temperature 110°C  
Reaction to Fire Class A1  
Made in Turkey

Kudox Limited - 1 Bray Place - London - SW3 3LL  
Technical Support e-mail - support@kudox.com  
Technical Support Phone - 020 75899617  
FAQ & Advice - www.kudox.com

1. Screw the Blank Plug and the Air Vent Plug into the top two threads in the upright channels. Tighten firmly with a 22mm or adjustable spanner.
2. Wind a thick layer (at least 6 turns) of PTFE tape, clockwise around the radiator valve tails (not supplied) & screw the radiator valve tails into the bottom two threads in the upright channels & tighten firmly with a 22mm or adjustable spanner.
3. Check that the wall is strong enough to hold the weight of the towel rail. Mark your preferred bracket positions on the wall and drill holes for the fixings you intend to use. The Wall Plugs supplied are only suitable for solid walls and you will need alternative fixings for other wall types.
4. Screw the Bracket Bases to the wall using the Washers & Wall Screws provided or alternative fixings. The holes for the Mini Screws should be facing downward.
5. Screw the Bracket Stems into the threads on the back of the towel rail.
6. Align the Bracket Stems with the Bracket Bases and push the towel rail back into position.
7. Push the radiator flat against the wall and insert the Mini Screws into the bottom of the Wall Supports and tighten with a screwdriver.
8. Connect the radiator valves (not supplied) and fill the system to check for leaks and fix as necessary.
9. Flush the entire system with a DWTA approved central heating cleanser and then refill using a DWTA approved central heating protector.
10. Run the system up to full temperature and release any trapped air using the Air Vent Plug and the installation is finished.

